



THIS PICTURE SHOWS A FULL REPLACEMENT FASCIA BOARD FITTED TO 12MM PLYWOOD, WHICH IS NAILED TO THE END OF THE TIMBER JOISTS. FASCIAS SHOULD NOT BE DIRECTLY NAILED TO THE RAFTERS END GRAIN AS THE GUTTERING WILL ONLY BE FIXED TO THE PVCU FASCIA AND THIS WILL NOT BE ENOUGH WHEN WE HAVE SNOW IN THE GUTTERING. SOFFITS CAN BE FITTED IN TO AN EDGE TRIM AS SHOWN, THERE IS NO NEED FOR ANY BACKING TIMBER WITH THIS TYPE OF SOFFIT



THIS PICTURE SHOWS A UPVC COVER FASCIA BOARD INSTALLED OVER THE EXISTING TIMBER ,FASCIAS SHOULD BE DOUBLE NAILED AT 600MM CENTERS, ITS BEST TO KEEP THE STAINLESS STEEL NAILS UP ABOVE THE CENTER OF THE FASCIA BOARD SO THE GUTTERING SYSTEM WILL COVER THEM.



THIS PICTURE SHOWS THE END OF A BARGE BOARD WHERE IT MEETS THE EAVES FASCIA BOARD

SUBJECT TO SURVEY WE RECOMMEND THAT THE CEMENT VERGE IS INSPECTED AND RENEWED AT THE TIME OF OVERCLAD OR REPLACEMENT FASCIA AND SOFFIT.